

6CH Channel mode

1 CH	2 CH	3 CH	4 CH	5 CH	6 CH
Red	Green	Blue	White	UV	Amber

KRATOS

DMX CHART

10CH Channel mode

1 CH	2 CH	3 CH	4 CH	5 CH	6 CH	7 CH	8 CH	9 CH	10 CH
Red	Green	Blue	White	UV	Amber	Dimmer	Strobe	color walking	Sound control
							0~7 No function 8~99 Strobe(from slow to fast) 100~149 Strobe(from fast to slow) 150~199 Strobe effect 1 200~245 Strobe effect 2 246~255 Strobe, the fastest strobe effect	0~7 No function 8~255 color auto	0~7 No function 8~199 color auto speed 200~255 Sound control