

Vulcan Aether Batten

74 CH Mode

Channel	Name	Zone
	1 Dimmer	Main
	2 Shutter	Main
	3 Red	1
	4 Green	1
	5 Blue	1
	6 White	1
	7 Red	2
	8 Green	2
	9 Blue	2
	10 White	2
	11 Red	3
	12 Green	3
	13 Blue	3
	14 White	3
	15 Red	4
	16 Green	4
	17 Blue	4
	18 White	4
	19 Red	5
	20 Green	5
	21 Blue	5
	22 White	5
	23 Red	6
	24 Green	6
	25 Blue	6
	26 White	6
	27 Red	7
	28 Green	7
	29 Blue	7
	30 White	7
	31 Red	8
	32 Green	8
	33 Blue	8
	34 White	8
	35 Red	9
	36 Green	9
	37 Blue	9
	38 White	9
	39 Red	10
	40 Green	10
	41 Blue	10
	42 White	10
	43 Red	11

DMX CHART

44 Green	11
45 Blue	11
46 White	11
47 Red	12
48 Green	12
49 Blue	12
50 White	12
51 Red	13
52 Green	13
53 Blue	13
54 White	13
55 Red	14
56 Green	14
57 Blue	14
58 White	14
59 Red	15
60 Green	15
61 Blue	15
62 White	15
63 Red	16
64 Green	16
65 Blue	16
66 White	16
67 Red	17
68 Green	17
69 Blue	17
70 White	17
71 Red	18
72 Green	18
73 Blue	18
74 White	18

9CH Mode

- 1 Dimmer
- 2 Shutter
- 3 FX
- 4 FX Speed
- 5 Colour Macros
- 6 Red
- 7 Green
- 8 Blue
- 9 White

6CH Mode

- 1 Dimmer
- 2 Shutter
- 3 Red
- 4 Green
- 5 Blue
- 6 White